

Maestro 75 Tunnel RCH Maestro 75 Tall Tunnel RCH

G20/G25/G25.3 (Natural gas), G30 (Butane) and G31 (Propane)



English Store this document in a safe place



Scan this QR-Code for DRU Video Assist

Content	
1. Step-by-step installation plan	4
2. Introduction	5
3. EU Declaration of conformity	5
4. Technical data	6
5. SAFETY	7
5.1 General	7
5.2 Regulations	7
5.3 Safety instructions	7
6. Preparation	8
6.1 Unpacking	8
6.2 Type of gas	8
6.2.1 Gas type conversion	8
6.3 Gas connection	8
6.3.1 Gas hose for gas outlet	9
6.4 Electrical connection	9
6.5 Components of the appliance control unit	10
7 Installatie	11
7.1 Placing the appliance	11
7.1.1 Maestro 75 Tunnel	11
7.1.2 Maestro 75 Tall Tunnel	11
7.2 Additional installation options of the construction frame	14
7.3 Concentric system	15
7.3.1 General	15
7.3.2 Roof terminal (C31)	17
7.3.3 Wall terminal (C11)	20
7.3.4 Connection to an existing chimney (C91))	23
7.4 Placing the chimney breast	23
7.5 Placing the control hatch	26
8 Appliance	28
8.1 Glass panes	28
8.1.1 Opening the glass pane	28
8.1.2 Removing the glass pane (Maestro 75 Tunnel RCH)	28
8.1.3 Removing the glass pane (Maestro 75 Tall Tunnel RCH)	28
8.1.4 Placing the glass pane	30
8.2 Setting the appliance	31
8.2.1 Restrictor slide	31
8.2.2 Air inlet guide	32
8.3 Placing the wood set	33
8.3.1 Wood set	33
9. Control/operation	43
9.1 Igniting the appliance	44
9.2 Connection switch contact (Eco Glow)	45
9.3 Switching/Dimmable power supply (Triac)	45
9.4 Operation	45

9.4.1 Remote control	45
9.4.2 DRU Fire App - User	45
9.4.3 DRU Fire App – Service	45
9.5 Wired home automation system	46
10. Final inspection	48
10.1 Gas tightness	48
10.2 Gas pressure/line-pressure	48
10.3 Ignition main burner	48
10.3.1 First ignition of the appliance after installation or adjustments	48
10.3.2 Igniting the burner(s)	49
10.4 Flame picture	49
11. Delivery	50
12. Maintenance	51
13. Parts	51
14. End of life/Recycling	51
Appendix 1: Malfunctions	52
Appendix 2: Technical data (EU) 2024/1103	54

The major points of attention of the installation are described in the check list below. Perform these steps and tick them

	once they have been performed correctly. After ticking all the steps, the appliance will be ready for use.
	The correct appliance has been supplied (see table 4-1)
\bowtie	The appliance is free from damage
\geq	All supplied parts are present (see table 6-1)
\searrow	The correct gas type and gas pressure is present on the location where the appliance will be placed
	The gas tap is within reach after installation and meets the legal requirements
	The gas connections are gas-tight (see section 10.1)
\bowtie	The concentric system has been installed in accordance with the imposed requirements (see section 7.3)

1. Step-by-step installation plan

 \wedge

Read the full installation manual prior to installing the appliance.

The total installation complies with national and local structural requirements and fire safety requirements

The chimney breast complies with the imposed fire safety requirements (see section 7.4)

The chimney breast complies with the minimum dimensions and has been provided with sufficient ventilation (see section 7.4)

The control hatch with the appliance control unit has been installed in accordance with the instructions (see section 7.5)

The restrictor slide and/or air inlet guide(s) have been adjusted correctly (see section 8.2)

The log, pebble or broken glass set has been placed as described (see section 8.3)

The remote control has been prepared for use (see section 9.5)

When the appliance is ignited for the first time, the glass pane has been removed (see section 10.3.1)

The glass pane(s) has/have been cleaned before the appliance with glass pane(s) is ignited (see section 12)

When igniting for the first time with glass pane, the appliance ignites correctly and the flame progress on the main burner is correct (see section 10.3.1)

The user has been familiarised with the appliance and its functions (see section 11)

2. Introduction

DRU, a manufacturer of gas-fired and electric stoves, develops and produces products that comply with the highest quality, performance and safety requirements. The information in this installation manual will ensure the appliance is installed in such a way that it will function safely and in a correct way.

Installation and maintenance of the appliance should be performed by a certified and competent professional person, hereafter referred to as the installer. Read the installation manual prior to installing the appliance and make sure the instructions contained therein are fully and carefully observed. If applicable, this also applies to the installation manuals for the DRU PowerVent[®] and the DRU CM system.

The appliance is supplied with an installation manual and a user manual. The installation manual discusses the installation of the appliance and the applicable instructions, includes the technical specifications of the appliance and provides information about its maintenance and any failures that might occur and what might cause these failures. The user manual contains all information that is relevant to the user in order to operate the appliance properly and safely. After final delivery, both manuals should be handed over to the user.

Where installation instructions are not clear, national/local legislation should be observed.

Symbols are used in the manuals to indicate important information:

- Work to be performed
- Tips and additional information
- ▲ Necessary instructions to prevent problems that might occur during installation and/or use
- ▲ Necessary instructions to prevent fire, personal injury or other serious damages

3. EU Declaration of conformity

This declaration of conformity is provided under the sole responsibility of DRU Verwarming, hereafter referred to as DRU. DRU declares that company internal measures guarantee that appliances produced by DRU meet the essential requirements and guidelines of the European regulation concerning gas-fired appliances and the accompanying standards. This declaration loses its validity if changes are made to the appliance without written permission from DRU. The instructions in the manuals must also be observed at all times. A copy of the EU test certificate can be downloaded via www.druservice.com.

Product: Type: Product identification number: EU test certificate: Conformity assessment body:

Regulations: Directives: Standards:

DRU Verwarming B.V. Postbus 1021, NL-6920 BA Duiven Ratio 8, NL-6921 RW Duiven www.drufire.com Gas-fired heating appliance Maestro 75 Tunnel RCH, Maestro 75 Tall Tunnel RCH 0063CS3282 18GR0736/02 Kiwa Netherlands B.V. (0063) Wilmersdorf 50 Postbus 137 7300 AC, Apeldoorn (EU) 2016/426, (EU) 2015/1186, (EU) 2024/1103 2014/53/EU, 2014/35/EU, 2014/30/EU, 2009/125/EC EN 613:2021, EN 60335-1:2012, EN 60335-1:2012/A2:2019, EN 60335-1:2012/A11:2014, EN 60335-1:2012/A13:2017, EN 60335-1:2012/A14:2019, EN 60335-2-102:2016

Signed for and on behalf of:



Duiven, 01-07-2025

4. Technical data

Check the technical data based on the table below.

Table 4-1:	Technical data (E	N613:2021 /	(EU)2015/11	86)		
Madel identifier(c) Maestro 75 Tunnel PCH / Maestro 75 Tall Tunne						
	Macst	io / 5 fumeri	Built-in		interi	
Combustion		Closed combustion				
Type		C11, C3	1, C91, C12, C	32****		
Categorie		I _{2F} , I	, 2E+, I _{2EK} , I _{2ELL} , I _{2H}	II _{2H3+} , II _{2E+3+} , II	2H3B/P, II _{2E3B/P} , II _{2E}	K3B/P
Concentric appliance connection	on			200/130		
Applicable concentric systems	5	DRU	LAS ES-I 200/	130, DRU LAS	ES-E 200/150/	/100,
			DRU LAS ES-I	150/100, DRU	J PV-I 100/60	
Flame protection version			Separated i	gnition / ioniz	ation plugs	
Pressure equalisation			E	xplosion hatc	h	
Max. temp. outer tube concentric s	ystem			150°C		
Radiation range safe distance (front	:/side)		70	0 mm / 500 m	im	
Ventilation hole chimney breas	st	V-in:	80 cm² (Eco G	low; 2 x 80 cm	1²) / V-out: 200) cm ²
Gastyne:	Symbol	625	620	630	631	Unit
Gustype.	Jynnoon	G25.3*	020	0.50	0.51	Onic
Indirect heating functionality		No	No	No	No	
Direct heat output		8.5 / 9.5	9,1 / 10,2	11.1 / 11.6	9.5 / 10.0	kW
Indirect heat output		-	-	-	-	kW
Space heating emissions NO,		85,0 / 59,4	90,9 / 66,2	61,7 / 66,3	51,5 / 57,0	mg/kWh _{input}
						(GCV)
Heat output						
Nominal heat output	P _{nom}	8,5 / 9,5	9,1 / 10,2	11,1 / 11,6	9,5 / 10,0	kW
Minimum heat output (indicative)	P _{min}	1,5 / 1,7	1,7 / 2,0	2,2 / 2,3	1,9 / 2,0	kW
Technical data						
Nominal heat input (Hs)		12,0 / 12,3	12,7 / 13,0	14,4 / 14,3	12,5 / 12,5	kW
Nominal heat input (Hi)		10,8 / 11,1	11,5 / 11,1	13,3 / 13,2	11,5 / 11,5	kW
Consumption max		1294/1318	1209/1224	409 / 407	467 / 469	L/h
Consumption min		221/245	232/258	87 / 83	100/96	L/h
Burner pressure max		18,7 / 19,0	15,0 / 15,0	27,2 / 26,8	27,3/27,2	mbar
Burner pressure min		3,8/4,7	3,7 / 4,7	10,0 / 8,5	9,0 / 8,8	mbar
Main burner injector		2x Ø1,62	2x Ø1,62	2x Ø1,10	2x Ø1,10	mm
		1xØ1,70	TX Ø1,70	IXØ1,15	IXØ1,15	
Low sotting injector		Λ****	۸****	۸****	Λ****	mm
Efficiency class (EN613)		1	1	1	1	111111
Liseful efficiency (NCV)**		1	1	1	1	
Useful efficiency at nominal heat output	n.	930/930	930/920	943/932	936/933	%
Useful efficiency at minimum heat output	n _{th min}	83.0 / 92.8	83.1 / 92.4	92.2 / 92.8	92.1/92.9	%
(indicative)	• [tn,min	00,0, 22,0	00,1, 22,1	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,.,,.	,
Auxiliary electricity consumption						
At nominal heat output	el _{max}	0,0236	0,0236	0,0236	0,0236	kW
At nominal heat output	el _{min}	0,0125	0,0125	0,0125	0,0125	kW
In standby mode	el _{sb}	0,0026	0,0026	0,0026	0,0026	kW
Permanent pilot flame power requirement						
Pilot flame power requirement (if applicable)	P _{pilot}	-	-	-	-	kW
Energy efficiency***						
Energy efficiency index	EEI	92 / 92,5	92 / 91,6	94 / 92,8	93 / 92,8	
Energy efficiency class		A	A	A	A	
Type of heat of	output / room ten	perature con	trol			
Single stage heat output, no room temperature control						No
I wo or more manual stages, no room temperature control						No
With mechanic thermostat room temperature control						INO
With electronic room temperature control						Yes
With electronic room temperature control plus day timer						Vec
	Other control ont	ions				165
Boom temperature control with presence detection						Yes***
Room temperatu	re control, with on	en window det	ection			Yes***
With distance controle option					Yes	

* This appliance is suitable for G25.3 with the composition according NTA 8837. ** System efficiency. ***(achieved) using home automation. **** Adjusting screw. *****Categories C12 and C32 only in combination with DRU PV-1 100/60 (PowerVent[®]).

5. SAFETY

 \wedge

5.1 General

- Observe the generally applicable regulations and precautions/safety instructions in this manual.
- Read this manual carefully to ensure the proper and safe installation of the appliance.
- Prior to starting the installation, check that the correct appliance has been delivered on the basis of table 4-1.

5.2 Regulations

Please install the appliance in accordance with the applicable national, local and constructional (installation) regulations.

5.3 Safety instructions

- △ Carefully observe the following precautions/safety instructions:
 - Installation and maintenance of the appliance should be performed by an installer.
 - The appliance was designed for atmospheric and heating purposes. This means that all visible surfaces, including the glass pane, can become hotter than 100°C. It is recommended to always place a guard grille in front of the appliance when children, older people or persons with reduced physical, sensory or mental capacities are in the same room as the appliance. If these vulnerable people are regularly present in the room without supervision, a fixed guard should be made around the appliance.
 - Keep combustible objects and/or materials outside the appliance's radiation range (see section 7).
 - Do not cover the appliance and/or do not wrap it in an insulation blanket or any other material.
 - Do not use the appliance when a pane is broken and/or cracked, until it has been replaced.
 - Only use the flue gas discharge / combustion air supply system (concentric system) supplied by DRU.
- Men installing the appliance, heed the following warnings:
 - Do not make any changes to the appliance.
 - Only use the accompanying set, such as the wood or pebble set, and place it exactly as described.
 - Leave space around the ionisation pin and spark electrode and never place glow material around these pins.
 - Place a gas tap in accordance with applicable regulations.
 - Make sure there is no dirt in gas pipes and connections.
 - Check the complete installation for gas tightness prior to commissioning.
 - Do not ignite the appliance until it is fully installed in relation to the gas connections, discharge system and electrical components.

Mhen installing a built-in appliance:

- Prevent the explosion hatch(es) on the top of the appliance (if present) from getting clogged and check that they properly fit on the sealing surface, before the appliance is built in.
- Use non combustible and heat-resistant materials for the chimney breast, including the top of the chimney breast and the material in the chimney breast, such as the floor under the appliance and the back wall against which the appliance will be placed. For this you can use both special sheet material and stone-like materials.
- Take sufficient measures to prevent excessive temperatures of a wall behind the chimney breast, including the materials and/or objects behind the wall.
- Take the minimum required internal dimensions of the chimney breast into account. These are for the benefit of safety and for the prevention of excess heat accumulation in the chimney breast.
- Ventilate the chimney breast by means of ventilation holes (see section 7). These are essential for safety and for the prevention of excess heat accumulation in the chimney breast.
- Make sure that the construction materials used to build the chimney breast do not obstruct or block the incoming and outgoing airflow. The space above the front window, behind the construction frame, and the control hatch are essential entrances for the incoming air flow.
- Use heat resistant electrical connectors.
- Place heat-resistant electrical wiring away from the appliance and as low as possible in the chimney breast. This has to do with the temperature development in the chimney breast.

Men installing a free-standing appliance:

- Place the appliance at the indicated minimum distance from the back wall and side walls (see section 7).

6. Preparation

 \geq

6.1 Unpacking

When unpacking the appliance, please proceed as follows:

- Remove all packaging materials and dispose of them by means of the correct waste processing method.
- Keep plastic bags and packaging materials away from children.
- Remove all supplied components in, on and/or at the appliance.
- Remove the screws, if the appliance is attached to a platform or pallet.
- Check the appliance and accessories for damages (during transport). In case of damage, contact your supplier.
- Never install a damaged appliance.
- Use table 6-1 to check if all components have been delivered. Contact your supplier if this is not the case.
- . (...) The glass panes are made of ceramic material, which means that minor irregularities in the surface cannot be prevented. These are within the imposed quality standards.

Table 6-1: Parts included with the delivery	
Part	Amount
Installation manual	1x
User manual	1x
Wood set (including: chips, vermiculite and ash)	1x
Glowing Embers set (if applicable)	1x
Glow material	1x
Ash	1x
Restrictor slide (L2)	2x
Remote control	1x
Mains lead	1x
Control hatch	1x
Back-up self-tapping screws for benefit of glass pane assembly	nx
Compression fitting 15 mm x G3/8"	1x
Socket spanner 8 mm	1x

6.2 Type of gas

 \wedge

 \wedge

The data plate indicates for which type of gas, gas pressure and for which country this appliance is intended. The data plate can be found on the appliance or can be attached to a chain to which it should remain attached. Check whether the appliance is suitable for the type of gas and the gas pressure used at the location.

6.2.1 Gas type conversion

In order to convert this appliance to a different type of gas, please contact DRU's service department and ask for the possibilities. The conversion should be performed by a recognised gas installer.

6.3 Gas connection

This appliance is intended for use on a gas installation with a gas pressure regulator in the supply. In addition, a gas tap should be installed in the gas pipe, in conformity with the applicable regulations.

- Make sure the gas pipes and connections are free from dirt.
- No soldering work may be performed at the flexible gas hose(s).

For the gas connection (fig. 6-2 (Gin)), the following requirements apply:

- Lay the gas pipe in such a way that no pressure loss can occur.
- The gas tap must be provided with the correct quality mark.
- The gas tap should be accessible at all times during and after installation.

6.3.1 Gas hose for gas outlet

 \wedge

If legally permitted, a gas hose for a gas outlet (according to EN14800) can be ordered with the appliance in various lengths (consult DRU Service for this). The gas hose is mounted to the appliance at factory and has been checked for leak-tightness.

- The gas outlet should be accessible at all times during and after installation.
- The gas outlet may only be placed vertically (see fig. 6-1).
- The gas outlet and gas hose may not be placed behind the appliance.
- The gas outlet should be placed next or under the appliance on the wall behind the appliance.
- Measured from the bottom of the adjustable foot holder, a maximum allowed placement height of 30 cm shall apply (see fig. 6-1).
- A minimum radius of 40mm must be observed in case of a bend in the gas hose (see fig. 6-1).
- A minimum distance of 20mm must be observed between gas hose and appliance.
- The gas hose must be placed as low as possible in the chimney breast. Place it as far away from the burner as possible.
- The input of the appliance control unit points towards the appliance. Due to the bend radius of the gas hose, the chimney breast width becomes larger on the side of the control hatch.

6.4 Electrical connection

Ensure a 230 Volt earthed electrical connection. Place this connection in such a way that it is free from the appliance. When using a chimney breast, the connection should be placed as low as possible, in connection with the temperature development during use.

- ▲ Make sure the installation can be made free from voltage easily after installation, by disconnecting the plug or using a 2-pole switch placed by an installer in accordance with normal regulations.
- Protect the appliance control unit and accompanying electrical components against building dust and building moisture.
 - When connecting the receiver and the control panel of the CM system, observe the instructions in the provided installation manual.



6.5 Components of the appliance control unit

The appliance control unit consists of the following components (see fig. 6-2):



- A: Distribution block; connection of the burners
- B: Main valve; controls the gas supply to the main burner and valve second burner.
- C: Valve second burner; switches the gas supply to the second burner (if applicable)
- D: Controller (ESYS); controls the ignition procedure and checks for a safe operation
- E: Receiver (DFGT); ensures the control of the appliance
- P1: Pressure gauge nipple 1; burner pressure
- P2: Pressure gauge nipple 2; line-pressure

 $G_{\mbox{\tiny (IN)}}$: Gas connection; connection from the gas control to the gas network

7 Installatie

 \wedge

7.1 Placing the appliance

Separate sections describe different ways of placing the appliance. The general description below for placing the appliance applies to all these sections:

Place the appliance on the location where it will be installed and take the following into account:

- The construction dimensions of the appliance (see fig. 7-1 and 7-2).
- The minimum chimney breast dimensions (see section 7.4).
- The length of the cables and pipes (see section 7.4).
- Place the appliance in front of heat-resistant and non combustible walls and on a heat-resistant and non combustible floor.
- The wall brackets on a built-in appliance ensure that the minimum distance to the wall is maintained (see fig. 7-1 (B)).
- Take sufficient measures to prevent excessive temperatures of a possible wall behind the chimney breast, including the materials and/or objects behind the wall.
- Make sure there are no combustible objects or materials within the radiation range of the appliance (see fig. 7-12).
- Place the concentric system in such a way, that it is impossible for a fire hazard to occur (see section 7.3).
- Do not cover the appliance and/or do not wrap it in an insulation blanket or any other material.
- Make sure that the appliance to be installed has a stable position. Fasten possible extending legs with the self-tapping screws.
- Set the height of the appliance using the adjustable feet and level the appliance.
- Attach the appliance to the wall using wall brackets (see fig. 7-1 (B) and fig. 7-2 (B)).
- Loosen the appliance control unit with transport bracket from the appliance, by loosening the self-tapping screws and screw the self-tapping screws back in the appliance.
- Place the appliance control unit, together with the wiring of the ignition/ionization cable(s), the flexible gas hose(s) and the data plate with chain in the direction of the control hatch (see section 7.5).
- ▲ Ensure the cables of the ionization and ignition pins are lying free from metal parts as much as possible and are lying fully free from signal and voltage cables.
 - The data plate must remain attached to the appliance by means of the chain at all times.

7.1.1 Maestro 75 Tunnel

Make sure that the appliance to be installed has a stable position. Fasten possible extending legs with the self-tapping screws. Anchor appliance to the wall and/or ceiling using the mounting bracket on top. (see Fig. 7-1 (B)).

7.1.2 Maestro 75 Tall Tunnel

The height of the device makes it top-heavy, in addition, there is a large shift in weight when opening the window system. Therefore, ensure that the appliance is stable and anchored to the wall and/or ceiling. Use the mounting plate (see Fig. 7-2 (B)) and, for example, connect it to the ceiling using the appropriate mountin hardware.

△ Incorrect and/or inadequate anchoring of the appliance can cause it to fall over.





7.2 Additional installation options of the construction frame

The construction frame of this appliance can be adjusted from the "4S version" to the "3S version" (see fig. 7-3). The 3S version allows you to fit the glass pane against the floor or platform.

- When using the 3S construction frame, the platform or floor in front of and next to the appliance has to be made with \wedge inflammable material (see section 7.4)
- \mathbb{A} No other information can be provided, nor can responsibility be accepted for the way in which floor covering or other materials are influenced by the use of this appliance (e.g. the 'working' of a wooden floor). This despite adhering to the minimum required distance to non combustible floor covering or other materials.

When choosing the 3S version, the lower strip of the construction frame has to be removed before this appliance is installed.Proceed as follows:

- Remove the Allen screws with an Allen key.
- Hold the strip and unscrew the self-tapping screw.
- Remove the strip.



7.3 Concentric system

7.3.1 General

The appliance is connected to a flue gas discharge / combustion air supply system delivered by DRU, hereafter referred to as the concentric system. DRU has different concentric systems in its range.

In the case of a concentric system, the inner tube is used as flue gas discharge. The combustion air is supplied by the outer tube. As a result, the latter always has a relatively low temperature. For the maximum temperature of the outer tube, see the technical data in table 4-1. The concentric system has been tested in combination with the appliance. Other concentric systems are not permitted.

See the table below for the different concentric systems of DRU and their application:

Table 7-1: Concentric systems and their application						
System	Permitted for this appliance.	Remarks				
DRU LAS AG-I 150/100	No	Alu-galva tubes for use inside the building*.				
		Diameter Ø150/100 mm.				
		Cannot be combined with the SS systems.				
DRU LAS ES-I 150/100	Yes	SS tubes for use inside the building*.				
		Diameter Ø150/100 mm.				
		Using an SS adapter, it is possible to construct further with the				
		insulated LAS ES-E 200/150/100 system.				
DRU LAS ES-I 200/130	Yes	SS tubes for use inside the building*.				
		Diameter Ø 200/130.				
		Using an SS adapter, if permitted, it is possible to construct further with				
		LAS-ES-I 150/100.				
DRU LAS ES-E 200/150/100	Yes	Insulated SS tubes.				
		Discharge diameter Ø150/100.				
		External diameter Ø 200 mm.				
		Intended for use inside or outside building for placement in, for example,				
		timber frame construction, execute with 0 mm distance along combustible				
		material etc. It is not possible to continue building with an SS adapter with				
		LAS ES-I 150/100.				
DRU PV-I 100/60	Yes	Optional discharge system with fan for discharge up to approx. 60 metres				
		long.				

* With the exception of the components intended for that purpose, such as roof and wall terminals.

The diameter of the concentric system appliance connection can be found in table 4-1. By means of natural draft, the flue gases are discharged to the outside, this can be achieved by means of a wall terminal (C11) or a roof terminal (C31). If necessary, an existing chimney can be used (C91, see section 7.3.5).

In addition, if combined with PowerVent[®] (C12, C32), it is possible in many cases to discharge the flue gases with a smaller diameter (DRU PV-I 100/60).

- Only use the concentric system supplied by DRU This system has been tested in combination with the appliance. DRU cannot guarantee a proper and safe operation of other systems and does not accept any responsibility or liability for this.
- Use a chimney kit for making a connection to the chimney; this can be supplied by DRU.
- For terminals, observe the information in table 7-2.

Table 7-2: Terminals							
	Hole diameter and execution						
		Combustible material		Non combustible material			
System	Ø (mm)	Notes	Ø (mm)	Note			
DRU LAS AG-1 150/100 DRU LAS ES-I 150/100	≥250	The terminal hole may be covered with a rosette made of	≥154	Make terminal hole all around 2mm larger than the diameter of the			
DRU LAS ES-I 200/130 DRU PV-I 100/60 (also see: installation manuel PowerVent®)	≥300 ≥200	non-combustible material. This terminal hole must be ventilated. A 2 mm wide ventilation opening around the tube is sufficient. The space between the tube and the combustible material may not be filled with insulation material.	≥204 ≥104	concentric system to prevent "ticking"and such like. The terminal hole does not require ventilation.			
DRU LAS ES-E 200/150/100	≥204	The distance from combustible material may be 0 mm. The terminal hole does not require ventilation. If a clip binding is placed in a terminal hole, a hole diameter of Ø230 mm must be maintained.	≥204	Make terminal hole all around 2mm larger than the diameter of the concentric system to prevent "ticking" and such like. The terminal hole does not require ventilation. If a clip binding is placed in a terminal hole, a hole diameter of Ø230 mm must be maintained.			

- Maintain a distance of at least 50 mm between the outside of the concentric system and the walls and/or ceiling. If the system is built in (for instance) a cove, it should be made with non combustible, heat-resistant material all around it. This does not apply to the insulated concentric system (DRU LAS ES-E 200/150/100).
 - Some heat-resistant insulation materials contain volatile components that will spread an unpleasant smell for a prolonged time; these are not suitable.
 - The concentric system is constructed from (the flue spigot of) the appliance.

If, due to constructional circumstances, the concentric system is placed first, it is possible to connect the appliance by means of a telescopic pipe piece.

Place the concentric system as follows:

- Build the system up from (the flue spigot of) the appliance.
- Connect the concentric pipe pieces and, if necessary, the bend(s).
 Apply a clip binding with silicon sealing ring on each connection (
- Apply a clip binding with silicon sealing ring on each connection (does not apply to DRU LAS ES-E 200/150/100, here the sealing ring is inside the tube).
- Use a sheet metal screw to fix the clip binding to the pipe on locations that cannot be reached after installation.
- Attach the concentric system with sufficient fastening brackets, so that the weight is not resting on the appliance. Observe the following;
 - Place the first fastening bracket 0.5 metre from the appliance, at the most.
 - Place a fastening bracket maximum 0.1 metre from each bend, if the bends are more than 0.25 metre away from each other. If two bends are closer to one another than 0.25 metre, 1 fastening bracket between these bends will be sufficient.
 - At least every 1 metre, place a fastening bracket at slanted and horizontal sections.
 - At least every 2 metres, place a fastening bracket at vertical sections.
 - Fasten a roof terminal with anchor cables, if it protrudes more than 1,5 metres above the terminal.
- Determine the remaining length for the wall or roof terminal and cut it to size, make sure the correct insertion length is maintained.
- Place the wall terminal with the (groove/folded) seam at the top. Attach the wall terminal from the outside by means of four screws.

÷@ʻ My Flue Assist is a DRU web application to check whether an intended concentric system is permissible and provides advice on how to adjust the appliance. Go to the DRU Service website for My Flue Assist. The information from the installation manual is always leading.

7.3.2 Roof terminal (C31)

The roof terminal can end in a sloping and a flat roof.

The roof terminal can be supplied with an adhesive plate for a flat roof or with a universally adjustable tile for a sloping roof.

When using a roof terminal (C31), the following applies:

The construction of the chosen system has to be allowed. The working method below indicates how the permissibility is determined of a concentric system when using a roof terminal.

- Count the number of 45° and 90° bends required (15° and 30° bends are also allowed; these are not counted).
- Count the total number of whole metres of horizontal pipe length.
- Count the total number of metres of vertical and/or sloping pipe length (roof terminal excluded).
- Find the number of required bends and the total horizontal pipe length (see table 7-3, columns 1 and 2).
- AAAAAAAA Find the required total vertical and/or sloping pipe length (see table 7-3, row 1).
- A box with a letter means that the chosen concentric system is permitted.
- Determine the adjustment of the appliance (see table 7-4).
- Adjust the appliance correctly with, for instance, a restrictor slide and an air inlet guide (see section 8.2).

Roof terminal Maestro 75 Tunnel

- In case of a roof terminal without bends: first connect 0.8 metres of concentric system vertically on the appliance with \wedge a diameter of 200/130 mm. After the first 0.8 metres, reduce the concentric system to a 150/100 mm diameter, including a 150/100 mm roof terminal.
 - In case of a roof terminal with bends: first connect 0.8 metres of concentric system vertically on the appliance with a diameter of 200/130 mm. Make the concentric system with a 200/130 mm diameter, and reduce the concentric system immediately after the last bend to 150/100 mm, including 150/100 mm roof terminal.

Roof terminal Maestro 75 Tall Tunnel

- \mathbb{A} - In case of a roof terminal without bends: Directly reduce the concentric system to a 150/100 mm diameter, including a 150/100 mm roof terminal.
 - In case of a roof terminal with bends: Make the concentric system with a 200/130 mm diameter, and reduce the concentric system immediately after the last bend to 150/100 mm, including 150/100 mm roof terminal.

Table 7-3: Determination of the permissibility of a concentric system with roof terminal													
G20/G25/G25.3 G30/G31	Total number of metres horizontal		Total number of metres vertical and/or sloping pipe length										
	pipe length	1	2	3	4	5	6	7	8	9	10	11	12
No bends	0	В	В	С	С	С	С	D	D	D	D	D	D
2 bends	0	В	В	С	С	С	D	D	D	D	D	D	D
	1	A	В	В	С	С	С	D	D	D	D	D	
	2	A	A	В	В	С	С	С	D	D	D		
	3	A	A	А	В	В	С	С	С	D			
	4	A	A	А	А	В	В	С	С				
	5	A	A	А	А	Α	A	A					
3 bends	0	В	В	В	С	С	С	D	D	D	D	D	D
	1	A	В	В	В	С	С	С	D	D	D	D	
	2	A	A	В	В	В	С	С	С	D	D		
	3	A	A	A	В	В	В	С	С	С			
	4	A	A	A	А	В	В	С	С				
	5		A	Α	А	Α	A	A					
4 bends	0	В	В	В	В	С	С	С	D	D	D	D	D
	1	A	В	В	В	В	С	С	С	D	D	D	
	2	A	A	В	В	В	В	С	С	С	D		
	3	A	A	А	В	В	В	В	С	С			
	4		A	A	А	В	В	В	В				
	5			А	А	А	A	А					
5 bends	-												

Situation is not permissible. There are many more possibilities in combination with the DRU PowerVent[®] system (DRU PV-I 100/60) (see PowerVent[®] installation manual).

Table 7-4: Conditions for setting the appliance when using a roof terminal								
	G20/G25/G25.3/G30/G31							
Situation Air inlet guide Restrictor slide Restrictor slide (Distance in mm)								
А	YES (L1)	NO	-					
В	YES (L1)	YES	58					
С	YES (L1)	YES	50					
D	YES (L1 + L2)	YES	35					

▲ The concentric system in combination with a roof terminal (C31) needs to be reduced in diameter to 150/100 mm. See section 7.3.2 for further explanation and placement of the reduction.

7.3.3 Wall terminal (C11)

When using a wall terminal (C11), the following applies:

The construction of the chosen system has to be allowed.

- Check that the vertical pipe length falls between the minimum and maximum lengths (see table 7-5).
- Check that the horizontal pipe length (wall terminal excluded) falls within the minimum and maximum length (see table 7-5).
- ▲ In all tables below, 1 bend has been included in the concentric system. It is possible, however, to add extra bends. For each additional bend, the maximum allowed horizontal length of the concentric system is reduced. This is done as follows:
 - An additional 90° bend shortens the maximum allowed length of the concentric system by 2 metres.
 - An additional 45° bend shortens the maximum allowed length of the concentric system by 1 metre.
- At least 1 metre should always be placed on the appliance vertically, unless stated otherwise in the table.
- Determine the correct adjustment of the appliance (see table 7-5).
- Adjust the appliance correctly with, for instance, a restrictor slide and an air inlet guide (see section 8.2).

The rosette of the wall terminal is too small to seal the opening in case of passage through combustible material. That is why a heat-resistant intermediate plate of sufficient size should first be mounted to the wall. Then, the rosette is mounted on the intermediate sheet.

▲ When using a wall terminal, place the terminal with a downward slope of 1 cm / metre towards the outside, in order to prevent rain water from raining in.



- Only use 200/130 mm concentric system, including the 200/130 mm wall terminal.

- Factory settings: Air inlet guide mounted (L1) and installed restrictor slide (58mm).



- Only use 200/130 mm concentric system, including the 200/130 mm wall terminal.

- Factory settings: Air inlet guide mounted (L1) and installed restrictor slide (58mm).



Setting Maestro 75 Tunnel	Apply
Air inlet guide	L1
Restrictor slide	x

- Only use 200/130 mm concentric system, including the 200/130 mm wall terminal.

- Factory settings: Air inlet guide mounted (L1) and installed restrictor slide (58mm).



-Install a connecting piece reducing the concentric system to 150/100 mm directly onto the appliance.

- After this point, use only a 150/100 mm concentric system.

- Factory settings: Air inlet guide mounted (L1) and installed restrictor slide (58mm).



Use the 200/130 mm vertical length concentric system including bend, reduce concentric systemimmediately after the bend to 150/100 mm including 150/100 mm wall terminal (maximum 1 meter horizontal).
Factory settings: Air inlet guide mounted (L1) and installed restrictor slide (58mm).



- Only use 200/130 mm concentric system, including the 200/130 mm wall terminal.

- Factory settings: Air inlet guide mounted (L1) and installed restrictor slide (58mm).

7.3.4 Connection to an existing chimney (C91))

The appliance can be connected to an existing chimney (C91). A 100 mm diameter flexible SS pipe is placed in the chimney for discharging flue gases. The surrounding space is used as combustion air supply. Use the DRU spacer here. Place this spacer every three metres.

In case of an appliance connection of ø200/130, it should be reduced to ø150/100. See the situations in table 7-5 for the minimum vertical length of the reduction. The concentric system of 150/100 mm can be connected to an existing chimney.

The following requirements apply when connecting to an existing chimney:

- Only allowed when used in combination with the special DRU chimney connections. For a horizontal chimney connection, "Chimney connection stainless steel Ø150/100" must be used. For a vertical chimney connection, "Chimney connection plate Ø150" must be used.
- The internal dimension of the chimney should be at least Ø150mm and, in case of a square/rectangular chimney, at least 150x150 mm.
- The vertical length has a maximum of 12 metres.
- The total horizontal pipe length may have a maximum length. Bends smaller than 45° do not count as bends, but the sloping length thereof is included in the total length of the concentric system. See section 7.3.2.
- The existing chimney has to be clean.
- The existing chimney has to be tight.

The installation requirements for the flexible stainless steel pipe must be observed at all times.

- If the appliance is equipped with explosion hatches (see table 4-1), the minimum chimney breast dimensions as stated in section 7.1 must be complied with.
 - If the appliance is equipped with an explosion door (see table 4-1), it must be made sure that the existing surrounding structure is able to absorb sufficient heat to prevent overheating of electronic components.

For adjusting the appliance, the same conditions/instructions apply as for the concentric system described above.

7.4 Placing the chimney breast

 \wedge

For a good heat discharge and operation of the appliance, there should be sufficient space around the appliance. The chimney breast should be ventilated sufficiently by means of ventilation holes (incoming and outgoing).

- When an appliance is built in the floor, please take into account the minimum distances from the floor/ground in front of the appliance (see fig. 7-12).
- Use non combustible and heat-resistant material for both the surface below the appliance as the chimney breast (The top of the chimney breast, the material inside the chimney breast and the back wall of the chimney breast).
- The appliance is not a support structure. Make sure the appliance does not have to bear the weight of the chimney breast for example.
- The passage of the ventilation holes (outgoing) is stated in table 4-1. If it is not possible to use a control hatch in the chimney breast, an air supply of at least 80 cm2 must be placed as low as possible, but not above the burner surface. If a control hatch can be used, the control hatch will suffice as air supply (see section 7.5).

- \triangle When placing the chimney breast, you should take the following into account:
 - The minimum dimensions of the chimney breast surround (see fig. 7-13).
 - In case of the minimum width dimension, a centred placement of the appliance is presumed in order to guarantee sufficient convection (see fig. 7-13).
 - The location of the control hatch: this must be placed as low as possible.
 - The distance of the control hatch up to the side of the appliance (see fig. 7-14).
 - The dimensions of the control hatch (see section 7.5).
 - The location of the ventilation holes (V-out).
 - A minimum 100 mm distance between the top of the ventilation hole (outgoing) and the ceiling of the room.
 - The dimensions of the glass pane, so that it can be placed/removed after placing the chimney breast.
 - Protection of components and pipes of the appliance control unit against building dust such as cement and lime.
 - Placement of decorative strips, frames and such like; if possible, install these after the carrying out any structural work. If this is not possible, protect them during this work. Avoid the use of painter's tape. If this is not possible: use good quality painter's tape and remove this tape immediately after plastering or painting work (prolonged application of painter's tape may cause damage).
- ▲ You should preferably apply the ventilation holes (outgoing) on both sides of the chimney breast. Use the DRU ventilation elements.

Check the following items, before the chimney breast is fully closed:

- Is the discharge / concentric system placed correctly?
- Have the channels, fastening brackets and possible clip bindings, that become inaccessible later, been secured with self-tapping screws?
- Has no plastering work been performed on or across the edges of the construction frame? This due to the fact that: - the heat of the appliance could cause cracks;
 - It will no longer be possible to remove/place the glass pane.
- When using stone-like materials and or plaster finishing, allow the chimney breast to dry for at least six weeks prior to taking the appliance into operation in order to prevent cracks.





* Taking into account the control hatch, placed as indicated.

**If the appliance is installed low down in the chimney breast, a wider chimney breast must be created to accommodate the control hatch.

*** Maestro 75 Tall Tunnel RCH

▲ With Eco Glow appliances, an additional ventilation hole (V-in) must be installed. A ventilation inlet of 80 cm2 must be present on both sides to ensure sufficient cooling. No additional incoming ventilation hole is required if the appliance is placed at least 30 cm above the floor, in which case a single incoming ventilation hole of 80cm2 is sufficient



7.5 Placing the control hatch

In the control hatch, the appliance control unit, data plate and, if applicable, components of the DRU PowerVent[®] system are placed. The control hatch makes the measuring and adjustment facilities accessible and ensures a safe and optimum operation of the components. The use of a control hatch is not without significance. Not using a control hatch could void the warranty.

- A control hatch installed at the side of the chimney breast ensures an optimum connection between transmitter and receiver.
- A Placement of a control hatch also ensures the air supply in the chimney breast (V-in 80cm2).
- The control hatch and the bracket with the appliance control unit should always be placed indoors on a dry location.

When installing the control hatch, proceed as follows (see fig. 7-15):

- ▲ The appliance control unit must always be placed in the bottom left or bottom right of the control hatch. Other positions are not permitted (Step 1).
- Make an opening in the chimney breast as described in the manual for the control hatch (Step 2).
- The opening in the chimney breast may be made both horizontal and vertical.
- \triangle The bottom of the control hatch may not be placed higher in the appliance than the burner surface.
- Disassemble the outer frame with door from the inner frame. Attach the inner frame in the opening of the chimney breast (Step 3).
- When the chimney breast is made of bricks, the inner frame can be built in with bricks. In case of different materials, the inner frame can be glued or fastened with four countersunk screws, for instance.
- Attach the outer frame with door (3) to the inner frame using two Allen screws. The outer frame can be placed in such a way that the door turns to the left or right (Step 4).
- Unwind the cables. This will, amongst other things, prevent a poor operation of the ignition mechanism.
- ▲ Ensure the cables of the ionization and ignition pins are lying free from metal parts as much as possible and are lying fully free from signal and voltage cables.
- Roll out the flexible gas pipe(s) (Step 5).
- \triangle Avoid kinks in the pipes (Step 5).
- Mount the appliance control unit to the inner frame by allowing the Allen screw to fall in the lock opening on the long side. The opening on the short side will fall over the head of the Allen screw. Then fasten the appliance control unit with the Allen key to the long side (step 6).
- Remove the receiver by removing it from the bracket (Step 7).
- Connect the gas pipe (Step 8) (also see section 6.3).
- Bleed the gas pipe (Step 9).
- Connect the appliance to 230V earthed mains voltage by means of the provided mains cord (step 10). In order to make the appliance free from voltage, the plug can be removed from the appliance control unit.
- In case of damage to the mains cord, it should be replaced immediately by a cord of the same type.
- Place the data plate in its intended holder (Step 11).
- Always close the control hatch with the lock. The lock can be opened and closed with a flat screwdriver or coin for example (Step 12).



8 Appliance

8.1 Glass panes

The glass pane of this appliance is easy to open to allow cleaning of the inside of the pane. Before installing the wood set, adjusting the appliance or maintenance, the glass pane must be removed.

The glass pane is mounted in a steel frame. Only in case of a crack or break, it will be necessary to replace the glass pane in the steel frame. When the glass pane is referred to in this document, this will include the steel frame.

- Avoid damaging the pane during removal/placing.
 - Avoid/remove fingerprints on the glass pane, as they will burn into the glass.

8.1.1 Opening the glass pane

Proceed as follows to open the glass pane (see fig. 8-1).

- △ Only open the glass pane if the appliance is turned off and is at room temperature.
- Loosen the bolt from the lock bracket by 3 turns (See fig. 8-1 step 2a).
- Turn the lock bracket to the left by a quarter turn. This will unlock the lever, by means of which the glass pane can be opened. (See fig. 8-1 step 3a).
- ▲ Always prevent the glass pane from falling forwards.
- Pull the lever down, using your index fingers. Press down the glass pane while the lever is moved counter-clockwise by 180° and hold on to the glass pane! This will prevent the glass pane from falling forwards and getting damaged. Never leave the appliance in this position! (see fig. 8-1 step 4a).
- Carefully pull the glass pane towards the front with the two lips located at the left and right top side of the steel glass pane frame and then allow the glass pane to drop carefully. (see fig. 8-1 step 5a) The glass pane is now in the 'parked position'. (see fig. 8-1 step 6a).

8.1.2 Removing the glass pane (Maestro 75 Tunnel RCH)

Remove the glass pane by lifting it from the 'parked position'.

Grab the glass pane in the middle at both sides. Push the glass pane closed by a few centimetres and lift the glass pane in this angle vertically out of the pane guides. (see fig. 8-2).

8.1.3 Removing the glass pane (Maestro 75 Tall Tunnel RCH)

- Remove the decorative strip on the top of the window system.
- Simultaneously loosen the left and right brackets that guide the glass pane and connect it to the appliance (see fig. 8-3 step 1). Push close the glass pane with 2 persons at both sides, to such an extent that the brackets can be lifted from the guides. (See fig. 8-3 step 2)
- Then, carefully remove the glass pane with 2 persons from the lower glass pane guides at both sides of the appliance. (See fig. 8-3 step 3 and 4).





8.1.4 Placing the glass pane

Only replace the glass pane once it has been cleaned. Proceed as follows to close the glass pane. Placing the glass pane will take place in reverse order of removing the glass pane, as described in 8.1.1 to 8.1.3 (see fig. 8-1, 8-2 and 8-3):

- Avoid/remove fingerprints on the glass pane, as they will burn into the glass.
- $^{\odot}$ Lubricate rotating parts and glide planes with a heat-resistant lubricant, such as copper grease.
- Grab the glass pane in the middle, on the left and right side. Place the glass pane at an angle of approximately 45° with the lower cams of the glass pane in the guides (see fig. 8-2).
- Lower the glass pane in such a way that the upper cams fall on the entrances to the guides. Carefully lift the glass pane in order to lower the glass pane in the parked position.
- <u>A</u> Ensure the following, prior to closing the glass pane, in order to prevent damaging the glass pane:
 - Ensure the bracket is still around the bottom side of the glass pane, as required.
 Ensure there is no dirt between the glass pane and the appliance.
- First press the glass pane on its location on the upper corners and then hold the glass pane with 1 hand and lock the glass pane by sliding the lever clock-wise bij 180° (see fig. 8-1 step 3)
- ▲ By pushing the glass pane by one hand, the glass pane is prevented from getting damaged and it is prevented that the cams are not over the glass pane, as a result of which it would not close properly.
- Turn the lock bracket back to its original position and re-tighten the bolt (See fig 8-1 step 1).

8.2 Setting the appliance

The appliance has to be set in such a way that it works correctly in combination with the concentric system. For that purpose, a restrictor slide is possibly adjusted or removed and an air inlet guide is placed. The conditions for application with wall terminal and roof terminal are stated in tables 7-3 to 7-5.

This appliance is suitable for PowerVent[®]. For more information, please consult the PowerVent[®] installation manual.

8.2.1 Restrictor slide

The restrictor slide is mounted ex-factory. Adjust it, if necessary, or remove the restrictor slide (see appendix 3, fig. 9).

Follow the steps below for **adjusting** the restrictor slide:

- Unscrew the self-tapping screws of the plate in the top of the appliance.
- AAAA Remove this plate.
- Loosen the 2 self-tapping screws by a few turns.
- Adjust the position of the restrictor slide using table 7-4. The letter of the position on the restrictor slide corresponds with the letter of the situation.
- \triangleright Make sure that the point of the triangle belonging to the correct position and the centre of the self-tapping screw are exactly aligned.
- \triangleright Tighten the 2 self-tapping screws.
- \triangleright Place back the plate and fasten it with the self-tapping screws.

Follow the steps below for **removing** the restrictor slide:

- Unscrew the self-tapping screws of the plate in the top of the appliance.
- AAAAA Remove this plate.
- Unscrew the 2 self-tapping screws from the appliance.
- Remove the restrictor slide.
- Screw the 2 self-tapping screws back in the appliance.
- The self-tapping screws of the restrictor slide must have been screwed back in the appliance.
- Keep the restrictor slide, you may need it in future
- \geq Place back the plate and fasten it with the self-tapping screws



8.2.2 Air inlet guide

The air inlet guide assembly consists of an air inlet guide (L1); it is located under the vermiculite plate on the left and right side, the second air inlet guide (L2) is supplied separately.

When placing the air inlet guide (L2), proceed as follows (see fig. 8-6):

- Unscrew the self-tapping screws from the vermiculite plate and remove them from the appliance (see fig. 8-6, step 1).
- AAAA Unscrew the self-tapping screws of the air inlet guide (L1) on the left and right side (see fig. 8-6, step 2).
- Place the second air inlet guide (L2) on air inlet guide (L1) (2x) using the self-tapping screws (M) (see fig. 8-6, step 3).
- Place the air inlet guide assembly (L1 + L2) back in the appliance (left and right) and fasten it with the self-tapping screws (see fig. 8-6, step 4).
- \triangleright Place the vermiculite plate back in the appliance and fasten it with the self-tapping screws (see fig. 8-6, step 5).



8.3 Placing the wood set

The appliance is supplied with a wood set.

- \triangle The figures do not always show the correct colours.
- △ Observe the instructions below to prevent unsafe situations:
 - Only ever use the supplied wood set.
 - Place the wood set exactly as described.
 - Make sure the ionization and ignition electrodes and the surrounding space remain free(see fig. 8-7 and 8-8).
 - Prevent the fine vermiculite dust from ending up on the burner.
- A Place the logs exactly as described, otherwise:
 - The main burner will not ignite properly; which could result in unsafe situations.
 - The appliance will become filthy more quickly, as a result of soot.
 - The flame picture is affected.





8.3.1 Wood set

 \wedge

The wood set consists of a number of logs (see fig. 8-9), vermiculite (see fig. 8-10), chips (see fig. 8-11), glow material (see fig. 8-12) and ash (see fig. 8-13).

- For Eco Glow appliances, an extra set of Glowing Embers is supplied (see fig. 8-14).
- ▲ It is not possible to completely cover the Eco Glow openings in the plate around the burner, which means there is a risk of scattered light. This can be prevented as much as possible by the correct placement of Glowing Embers, coals and chips. Scattered light can also originate under, above and next to the appliance. Take this into account when designing the chimney breast.

Eco Glow appliances have a different type of base covering to appliances without Eco Glow.

- The vermiculite plates are provided with square holes, which ensure air supply. Do not place more than one layer of base covering over these holes.
 - Ensure that the base covering does not enter the slot for the glass pane.
- Fill the lying burner with vermiculite; evenly spread the vermiculite (see fig. 8-15). The vermiculite should not get higher than the edge of the burner.
- You can influence the flame picture by moving the vermiculite.
- A The vermiculite should not get higher than the edge of the burner.
 - The burner deck has to remain covered with vermiculite in order to prevent reduction of the burner's life span.













Identify logs A to K (see fig. 8-9).

- Use the burn stains on the logs for identification.
 - In the overview photograph, the side glass pane is located on the right side.
- Place log A over the lying burner in the positioning brackets (see fig. 8-20).
- Place log B on the left side behind log A, in the two positioning brackets and on log A.
- Place log C on the right side behind log A, in the positioning bracket and on log A, make sure there is 1 centimetre play between log C and the standing burner to the right (see fig. 8-20).
- Place log D in the positioning bracket to the right and on log C.
- Place log E against the tube of the standing burner to the right and in the positioning bracket.
- Place logs F and G in front of the lying burner, in the positioning brackets.
- Place log H against the tube of the standing burner to the left and in the positioning bracket.
- For appliances without Eco Glow, use all chips in the wood set.
- Fill the vermiculite plates with chips, spread the chips evenly, keep the sections marked in red free of chips (see fig. 8-18).
- For appliances with Eco Glow, use the Glowing Embers, coals and use 400ml of the supplied grey chips and 800ml of the black chips. This is less than the total ammount supplied with the appliance. Dispose of the surplus chips according to local laws.
- First place the glow rocks and then the coals. Switch on the glow lighting while placing, so that the stray light can be seen directly and covered with the rocks and coals.
- Spread the glow rocks over the grid pattern and square holes in the vermiculite plate, keep the sections marked in red free (see fig. 8-19).
- Spread the chips over the remaining sections, keep the sections marked in red free.
- Place log I on the left side in front of log A, in the positioning bracket and on log A.
 Make sure there is 1 centimetre play between log I and the standing burner to the left (see fig. 8-23).
- Place log J over the standing burner to the left, make sure the recess falls over the burner properly.
- Place log K over the standing burner to the right, make sure the recess falls over the burner properly.
- $\dot{\mathbb{Q}}$ Spread the ash over the chips and/or place the glow material over the lying burner in separate tufts.
- ▲ Prevent the ash from ending up on the burners.
 - Only place the glow material on sections that are marked green.
 - The areas around the ionization and ignition should remain free from glow material (see fig. 8-15).
 - The glow material may affect the colour of the flame picture.
- Place chips on the edge of he pane frame. Prevent chips from getting under the pane frame (see fig. 8-17).





















9. Control/operation

The appliance is supplied with a remote control. In addition, it is possible to operate the appliance via the DRU Fire App (available for iOS and Android). The user manual describes how the appliance is operated and how the remote control and DRU Fire App work.

The appliance can be operated by means of a home automation system, see section 9.6.

For the installer, there is a service menu in the DRU Fire App (available for iOS and Android) in which data of the appliance can be read (see section 9.5.3).

- Never ignite the appliance until it is fully installed in relation to the gas connections, discharge system and electrical components.
 - For an appliance made with the CM system, the regulations from the accompanying installation manual shall also apply.



9.1 Igniting the appliance

Igniting the appliance takes place as follows: the appliance is switched on by means of an ignition command. This can be done by means of the provided remote control, the DRU Fire App (iOS and Android) or a home automation system. The receiver in the appliance gets the signal to start the ignition process. The valves in the gas control are switched on and a reduced amount of gas flows to the main burner. The ignition mechanism sparks for 15 seconds, as a result of which the main burner ignites.

In the case of a PowerVent[®] system, the module switches on after an ignition command, as a result of which the fan of the system starts up. During starting up, a waiting time of 8 seconds applies. After this the appliance will ignite as described above.

After ignition of the main burner (half the capacity), the ionization is measured to check for a correct and full ignition of the burner. When no ionization is detected after 15 seconds, the ignition cycle is interrupted and the appliance will enter into a failure condition.

When ionization is detected, the main burner will switch to full capacity. In case of an appliance with a switching second burner, the gas valve is now opened to allow the second burner to ignite (shortly before ignition a click sound can be heard). The appliance is now in manual mode, runs at full capacity and is now ready for operation.

The second burner can be switched on and off manually by means of the remote control and/or DRU Fire App. After the second burner is switched on manually, the main burner first switches to full capacity to ensure a correct ignition.

The control unit of the appliance performs a safety check on the system every 24 hours. It is possible that this check is performed while the appliance is in operation. In that case, the appliance will extinguish and ignite again. Repetition at this particular time can be prevented by removing the plug from the socket and inserting it again at a time when the appliance is rarely or never burning.



9.2 Connection switch contact (Eco Glow)

(if applicable)

Connection (B) is used for the Eco Glow glow lighting (see fig. 9-2 (B)). When the appliance is not made with Eco Glow glow lighting, this contact can be used for other purposes. It is a potential-free contact and may be loaded to a maximum of 230V~ 1A (230W).

9.3 Switching/Dimmable power supply (Triac)

(if applicable)

With connection (C), it is possible, for example, to switch the lamps of DRU lux element or a ventilation system (see fig 9-2 (C)). This can be done by means of the provided remote control or DRU Fire App. The App can also be used to dim this contact. The power supply of this connection may only be loaded with up to 230V~ 0.35A (80 Watt).

9.4 Operation

9.4.1 Remote control

Proceed as follows to make the remote control ready for use:

- Place two AA type batteries in the battery compartment of the remote control.
- Ý After placing the batteries, the version number of the software on the remote control is briefly shown on the display.
- The display of the remote control now shows the message 'BND' and the Bluetooth symbol flashes. The remote control is now ready to be coupled with the appliance. See the user manual if the remote control is not in 'BND' mode.
- Make the appliance free from voltage for a short while by removing the plug from the appliance control unit and placing it back again.
- After briefly making the appliance free from voltage, it is possible to couple the remote control with the appliance for 5 minutes.
- Simultaneously press buttons 'ignition' and 'switch off' for 1 second.
- When coupling has been successful, the Bluetooth symbol lights up continuously and the current room temperature and possibility of ignition are shown.
- All functions of the remote control are explained in the user manual.

9.4.2 DRU Fire App - User

The DRU Fire App is available for both iOS and Android devices. Proceed as follows to couple the App with the appliance:

- There should always be an active coupling with the remote control before a device with App can be coupled with the appliance.
- Download the App and make sure Bluetooth is activated on the device to be coupled.
- Open the DRU Fire App and follow the steps in the App.
- For the thermostat function, the App will use the temperature sensor of the remote control. For a correct operation, the remote control should be within range and in the same room as the appliance.

9.4.3 DRU Fire App – Service

In addition to normal operation options, the App also has a service menu for dealers and service technician, in which the current status of the fire, the number of burning hours, the total number of error messages and the last 20 error messages can be read.

For this function you will need an account. For this, please contact DRU Customer Service.

9.5 Wired home automation system

(if applicable)

In addition to operation by means of the remote control and DRU Fire App, the appliance can also be operated via an external source. A wired home automation system can be directly connected to the receiver (see fig. 9-2 (D)).

- When the appliance is controlled by means of a home automation system, operation can be taken over by the remote control and/or DRU Fire App at any time. After having been taken over by the remote control and/or App, the home automation system should be reset to the zero position (0V) to allow operation of the appliance with this system again.
 - Wired connection of a home automation system to the receiver takes place via a 0-10V direct current (see fig. 9-2 (D)). By measuring the height of the voltage, the receiver knows to which position the appliance should be switched. Graph 9.1 shows the relationship between voltage, the height of the flame and the number of burners (1 or 2).
- A higher voltage than 10V will damage the receiver!

Proceed as follows when connecting the home automation system to the receiver:

- Connect the 0-10VDC signal to connection (D), to which a black (-) and yellow (+) wire are connected.
- Activate home automation in the service menu of the DRU Fire App before using it by changing the parameters of function '42003 Activate home automation' from 0 to 14.
- Switch off the burners using the home automation system.
- Measure the voltage on contact D. If $\geq 1,0V$ is measured, a 2200 $\Omega \geq 0.25W$ resistor (D^R) must be placed across contact D.
- \triangle Do not connect the resistor if <1,0V is measured.



10. Final inspection

 \wedge

 \mathbb{A}

For a good and safe operation of the appliance, the following checks must be performed prior to commissioning.

10.1 Gas tightness

▲ All connections must be gas tight. Check the connections for gas tightness. The gas control can be subjected to a maximum pressure of 50 mbar.

10.2 Gas pressure/line-pressure

The burner pressure is set at the factory; see data plate.

- The line-pressure in house installations must be checked, because it can be wrong.
- Check the line-pressure. See fig. 6-1 (P1) for the measuring nipple on the gas control.
 - Contact the gas company if the line-pressure is too high.
 - If the line-pressure is too low, check this at the gas meter. Contact the gas company if the line-pressure is also too low at the gas meter.

10.3 Ignition main burner

For igniting the main burner, see the User Manual.

10.3.1 First ignition of the appliance after installation or adjustments

- For inspection purposes, ignite the appliance without a glass pane after installation or after having performed work.
- If necessary, bleed the gas pipe.

Proceed as follows:

1. Remove the glass pane from the appliance (see section 8).

2. Ignite the appliance by means of the remote control or DRU Fire App. See section 9.1 for a step-by-step description of the ignition process. (Go to step 11 if the burner continues to burn).

If the main burner does not ignite:

3. Reset the system by means of the remote control or DRU Fire App.

4. Repeat the ignition procedure until the main burner ignites successfully.

- ▲ If the appliance does not ignite after three failed attempts, it will enter into a hard lock-out for 30 minutes in order to avoid a dangerous accumulation of gas. Make sure there is no more gas present in the appliance, before a new ignition attempt is made.
- △ Consult the diagram with error messages when ignition fails after a number of attempts (see appendix 1: Malfunctions).

5. Check the flame transfer on the main burner and check that the main burner continues to burn (go to step 11 if the burner continues to burn).

If the main burner does NOT continue to burn:

6. Mount the glass pane.

7. Reset the system by pressing the buttons 'Ignition' and 'switch off' on the remote control simultaneously.

8. Now ignite the main burner and check that it continues to burn (go to step 11 if the burner continues to burn).

Limit the ignition attempts with mounted glass pane to a MAXIMUM of 1 ignition attempt. Make sure there is no more gas present in the appliance, before a new ignition attempt is made.

If the main burner again does NOT continue to burn:

9. Switch off the appliance.

10. Consult the diagram with error messages (see appendix 1: Malfunctions) (Go to step 1 once the malfunction has been resolved).

If the main burner DOES continue to burn:

11. Clean the glass pane after taking into operation for the first time, as described in the user manual. Then mount the glass pane as described in section 8.

- 12. Repeat the ignition procedure a few times and perform checks as described in section 10.3.2.
- 13. The main burner should ignite smoothly at each attempt and should continue to burn.
- 14. Clean the glass pane after burning for the first time, as described in the user manual.
- ▲ Wait 5 minutes before you re-ignite the appliance.

When stoking up for the first time, set the appliance at full position. When the appliance is stoked up, the flame picture can be affected and an unpleasant smell may occur as volatile components evaporate. This process may take a number of hours. Properly aerate the room and remove pets from the room (see section 3 of the User Manual).

10.3.2 Igniting the burner(s)

 \wedge

- The ignition mechanism should ignite the main burner(s) within a few seconds and without popping.
- The main burner(s) must ignite smoothly, without popping and across the entire burner, and continue to burn.
- The second burner (if applicable) should ignite smoothly across the entire length of the burner(s) and continue to burn.
- If the appliance does not ignite after three failed attempts, it will enter into a hard lock-out for 30 minutes in order to avoid a dangerous accumulation of gas. Make sure there is no more gas present in the appliance, before a new ignition attempt is made. Ignite the appliance in the same way as the first ignition as described in section 10.3.1.
- Check the correct ignition of the main burner from cold condition.
- If sparks are observed between the electrodes of the ignition mechanism, the main burner should ignite within a few seconds.
- ▲ If NO sparks are determined, it is NOT permitted to continue the procedure. Consult the diagram with error messages (appendix 1: Malfunctions).

10.4 Flame picture

When stoking up for the first time, the flame picture is affected by the evaporation of, for instance, volatile components from paint and other materials. In case of a cold start, the appliance should first reach the correct temperature before the flame picture can be assessed.

- The flame picture and a good flame transfer can only be assessed when the glass pane is mounted and/or closed.
- Check that the flame picture is in order.
- Consult the diagram with error messages (appendix 1: Malfunctions) if the flame picture is not correct.

11. Delivery

During delivery, familiarise the user with the appliance and its operation. The user manual explains all aspects that are relevant to the user step by step, but this will never surpass a careful and personal instruction.

- \wedge Tell the user to close the gas tap immediately and contact a competent installer in case of malfunctions/poor operation. This to prevent unsafe situations.
- Provide the user with instructions for the appliance, remote control and DRU Fire App. \geq
- Give the manuals to the user (all manuals should be stored near the appliance).
- Important aspects for the benefit of the user's safety that the user must be familiarised with:
 - Opening and closing the control hatch
 - The operation and location of the gas tap
 - The location of the 230 Volt connection
- Inform the user about the following: \triangleright
 - In order to prevent cracks, a chimney breast made of stone-like materials or finished with plaster, must dry at least 6 weeks prior to taking the appliance into operation
 - Cleaning the glass pane(s)
 - In case of delivery of an appliance equipped with a DRU CM system, the Installation Manual will contain additional information about this

12. Maintenance

Once per year, the appliance must be checked, cleaned and, if necessary, repaired by a competent installer in the field of gas heating and electricity.

- ▲ Close the gas tap prior to starting maintenance work.
 - Make the appliance free from voltage prior to starting maintenance work.
 - Check the gas tightness after repair.
- △ Under no circumstances may a stainless steel concentric system be cleaned (internally) with a steel brush or metal sponge, for example. This will damage the oxide skin, as a result of which pit corrosion and/or system leakage could occur.
- Clean the glass pane(s), if necessary.
- Only clean a glass pane once it has reached room temperature.
 - Never use the appliance in case of a broken and/or cracked glass pane.
- \triangle Avoid damage to the glass pane(s).
 - Avoid/remove fingerprints on the glass pane(s), as these can burn into the glass.
 - Clean the glass pane(s) as described in the user manual.
 - Regularly remove accumulated dirt, as it can burn into the glass.
- Inspect the flue gas discharge system.
- ▲ You must always perform a final inspection.
- Perform the inspection as described in section 10.

13. Parts

For optimal operation and safety of the device, it is important to only use parts approved by DRU. Replacement parts are available via the official DRU Service website or from an approved DRU dealer. The use of non-approved parts will void the warranty.

14. End of life/Recycling

At the end of the use cycle, the device must be handed in at an approved collection point. When disposing of/recycling, follow the applicable national and local laws and regulations. If in doubt, contact the local authorities about the available options.

- Disassemble and/or remove the appliance only after it has cooled down to room temperature, has been completely disconnected from the power supply and has been disconnected from the gas supply.
 - The glass in the appliance is made of ceramic heat-resistant material and can therefore not be returned to a glass recycling point.

Appendix 1: Malfunctions

		Malfunctions	
Error code	Problem	Possible cause	Remedy
BND	No communication between	Remote control and receiver	Couple the remote control
	remote control and receiver (DFGT)	have not been coupled	with the receiver
		Remote control defective	Replace remote control
F01 E00	Communication loss between	Communication cable	Properly connect the
	receiver (DFGT) and controller (ESYS)	does not make contact	communication cable
		Communication cable defective	Replace communication cable
F01 E00	Malfunction Eco Glow [®] component(s)	Defective LED unit	Replace LED unit
		Defective LED driver	Replace LED driver
F02 E00	Receiver (DFGT) overheated (>70°C)	Poor ventilation at receiver	Improve ventilation at receiver
		Receiver makes contact with hot parts	Remove contact between the receiver
			and hot parts
F03 E00	Malfunction NTC sensor	NTC sensor incorrectly connected	Connect the NTC sensor in the correct way
		NTC sensor defective	Replace the NTC sensor
F05	Communication loss between	Remote control is out of	Bring the transmitter within the
LOST	transmitter and receiver (DFGT)	the receiver's range	range of the receiver
		Obstacles between remote control	Remove obstacles between
		and receiver	transmitter and receiver
		Transmission strength is too weak	Check transmission strength
			(see User Manual chapter 5.2)
F08 E01 E27	No ionization	No sparks	Check the distance between the electrodes
			(3-4 mm)
			Replace the electrodes
		No gas	Check gas supply
			In case of PowerVent [®] :
			check that gas valve opens
		Poor flame transfer main burner	Check the positioning
			of the logs and/or chips
			Remove dust that is present
			from burner openings
		No good flame under ionization pin	Check that the glass pane(s)
		(suffocating flame)	is/are mounted correctly
			Mount the restrictor and
			air inlet guide as described
			In case of PowerVent [®] :
			Check pressure settings
F08 E01 E02 E27	No ionization / false ionization	lonization pin positioned incorrectly	Position in the correct way
		Ionization pin blocked	Measure ionization current > $0.8 < 1.8 \mu A$
			Remove possible blockage with
			vermiculite and/or chips
		lonization pin defective	Measure ionization current
		f	Replace ionization pin when 0 µA
			,

Malfunctions						
Error code	Problem	Possible cause	Remedy			
F08 E03	High limit error	High limit bridge defective	Place High limit bridge on the controller			
F12 E12	EEPROM error	Controller defective	Replace controller			
F12 E13	Appliance is in lock-out	6 reset attempts within 15 minutes	Can be reset after 30 minutes			
F13 F14	Flame loss (no ionization) Only main burner	Short circuit on the ionization pin	Make the ionization pin free from chips,			
E01 E27	(F13) / Main burner + 2nd burner (F14)		vermiculite or glow material			
		lonization current critical (18 μA)	Increase ionisation current to \ge 1,8 μ A			
			by rearranging vermiculite and removing			
			chips and dust from the burner openings			
		Suffocation in the concentric system	Check the concentric system			
			Check the setting of the appliance			
		Suffocation when using PowerVent®	Check the pressure setting			
			of the PowerVent® system			
		24 hour check control (only F13)	Reset with remote control			
		Gas has fallen away	Restore the gas supply			
		Gas control defective	Replace the gas control			
F15 E04	APS malfunction	APS bridge defective	Place APS bridge on the controller			
	Fan PowerVent [®] does not start,	Fan is defective and/or	Replace the fan and/or			
	appliance does not spark	connected incorrectly	connect wiring correctly			
	Fan PowerVent® does start,	Leaking differential pressure hoses	Replace/repair connections and/or hoses			
	appliance does not spark					
		Differential pressure sensor defective	Replace differential pressure sensor			
		Control signal cable defective	Replace the control signal cable			
		Defect and/or leak in the concentric system	Check the concentric system for			
			leaks and defects. Repair if necessary			
F15 E09	No connection between control (ESYS)	Controller shot loose/mounted incorrectly	Mount controller correctly			
	and gas control					
		Controller mounted incorrectly	Mount controller correctly			
		Pins on the connector on	Bend them straight			
		the gas control are bent				
F15 E99	Error in wire connection	Controller connected incorrectly	Connect the wiring of the			
			controller correctly			
F16 E21 E25	Hardware Error controller (ESYS)	Controller defective	Replace controller			
F17	Hardware Error controller (ESYS)	Controller defective	Replace controller			
F18 E30	Controller (ESYS) is not released	Controller is in hard lockout	After 30 min. with mains voltage on			
			the appliance, F18/E30 can be reset			
No error code	The home automation system does	Floating voltage (≥1,0V)	Connect a resistor across contact D			
	not switch off the burners completely	on contact D	(Installation manual H9.5)			
L	1					

Appendix 2: Technical data (EU) 2024/1103

DRU Verwarming B.V.

Ratio 8, 6921 RW Duiven, The Netherlands

Model identifier(s)	Maestro 75 Tall Tunnel RCH		
Indirect heating functionality	-		
Minimum permissible total flue duct length	0 mVertical pipe0 mHorizontal pipe		
Fuel type	Gaseous		

	G25/G25,3	G20	G30	G31 I _{38/P}	G31 I _{3P}	
Heat output						
Direct heat output	8.8	9.3	10.9	9.4	-	kW
Indirect heat output	-	-	-	-	-	kW
Nominal heat output P _{nom}	8.8	9.3	10.9	9.4	-	kW
Minimum heat output (indicative) P _{min}	1.5	1.8	2.1	1.8	-	kW
Nitrogen oxides emissions NO _x	93.2	96.9	88.8	83.2	-	mg/kWh _{input} (GCV)
Auxiliary electricity consumption						
At nominal heat output eI _{max}	0.0236	0.0236	0.0236	0.0236	-	kW
At minimum heat output el _{min}	0.0125	0.0125	0.0125	0.0125	-	kW
Power consumption						
In off-mode P ₀	2.6	2.6	2.6	2.6	-	W
In standby mode P _{sm}	2.6	2.6	2.6	2.6	-	W
In idle mode P _{idle}	2.6	2.6	2.6	2.6	-	W
In networked standby mode P _{nsm}	2.6	2.6	2.6	2.6	-	W
Standby mode with display of information or status \checkmark						
Permanent pilot flame power requirement						
Pilot flame power requirement P _{pilot}	-	-	-	-	-	kW
Efficiency (NCV)						
Useful efficiency at nominal heat output $\eta_{\text{th,nor}}$	"	80.8	81.5	80.6	-	%
Useful efficiency at minimum heat output (indicative) $\eta_{\text{th,min}}$	74.0	74.1	78.5	77.2	-	%
Seasonal space heating energy efficiency $$\eta_{\mbox{\tiny s}}$$	74.2	74.6	75.2	74.4	-	%

38T-002

Type of neur output / room temperature control
--

Self-learning functionality

Control accuracy

Single stage heat output, no room temperature control	-
Two or more manual stages, no room temperature control	-
Mechanic thermostat room temperature control	-
Electronic room temperature control	√
Electronic room temperature control plus day timer	√
Electronic room temperature control plus week timer	V
Other control options	
Room temperature control, with presence detection	-
Room temperature control, with open window detection	-
Distance control option	√
Adaptive start control	-
Working time limitation	-
Black bulb sensor	-

-

-

DRU Verwarming B.V.

Ratio	8,6921	RW	Duiven,	The N	lether	land

hado o, osz r nw Dalven, me Nethenands							
Model identifier(s)	Maestro	Maestro 75 Tunnel RCH					
Indirect heating functionality	-						
Minimum permissible total flue duct length	0,8 m 0 m	Vertical pipe Horizontal pip	be				
Fuel type	Gaseous						
		G25/G25,3	G20	G30	G31 I _{3B/P}	G31 I _{3P}	
Heat output							
Direct heat output		8.6	9.2	11.0	9.4	-	kW
Indirect heat output		-	-	-	-	-	kW
Nominal heat output	P _{nom}	8.6	9.2	11.0	9.4	-	kW
Minimum heat output (indicative)	P _{min}	1.1	1.6	2.0	1.7	-	kW
Nitrogen oxides emissions	NO_x	75.0	81.5	102.4	92.3	-	mg/kWh _{input} (GCV)
Auxiliary electricity consumption							
At nominal heat output	el _{max}	0.0236	0.0236	0.0236	0.0236	-	kW
At minimum heat output	el_{min}	0.0125	0.0125	0.0125	0.0125	-	kW
Power consumption							
In off-mode	Po	2.6	2.6	2.6	2.6	-	W
In standby mode	P _{sm}	2.6	2.6	2.6	2.6	-	W
In idle mode	P_{idle}	2.6	2.6	2.6	2.6	-	W
In networked standby mode	P _{nsm}	2.6	2.6	2.6	2.6	-	W
Standby mode with display of information or status	~						
Permanent pilot flame power requirement							
Pilot flame power requirement	P_{pilot}	-	-	-	-	-	kW
Efficiency (NCV)							
Useful efficiency at nominal heat output	$\eta_{\rm th,nom}$	80.8	81.6	81.3	80.1	-	%
Useful efficiency at minimum heat output (indicative)	$\eta_{_{th,min}}$	58.5	71.0	69.5	69.8	-	%
Seasonal space heating energy efficiency	η	74.5	75.3	75.1	74.0	-	%

38T-003

Type of heat output / room temperature control

Single stage heat output, no room temperature control	-
Two or more manual stages, no room temperature control	-
Mechanic thermostat room temperature control	-
Electronic room temperature control	√
Electronic room temperature control plus day timer	√
Electronic room temperature control plus week timer	√
Other control options	
Room temperature control, with presence detection	-
Room temperature control, with open window detection	-
Distance control option	√
Adaptive start control	-
Working time limitation	-
Black bulb sensor	-
Self-learning functionality	-
Control accuracy	-



DRU Verwarming B.V. The Netherlands Postbus 1021, NL-6920 BA Duiven Ratio 8, NL-6921 RW Duiven